


# Compass Chair dimensions

User dimensions (inches)	R310 size 1	R320 size 2	R330 size 3	R340 size 4	R350 size 5
Height	36–43	43–48	48–55	55–63	63+
Knee to heel	9–11	10½–12½	12½–14½	14½–16½	16½–18½
 <b>Key user dimension: height</b> The user's overall height is a general guide to help you select the appropriate chair. Choose the model that allows for growth.					
	<b>Important:</b> Make sure that seat width, depth and height are adequate for each user, and that the user's weight does not exceed the maximum weight recommended.				
Item dimensions (inches)	R310	R320	R330	R340	R350
Seat height	9, 10, 11	10½, 11½, 12½	12½, 13½, 14½	14½, 15½, 16½	16½, 17½, 18½
Seat depth	9½	11	12¾	14¾	16½
Seat width	10½	12¼	14	16¼	18¼
Backrest height	9½	11	12½	14¼	16
Armrest height above the seat	5½	6	7	8¼	8¾
Armrest length	6½	7½	8½	9¾	11
Max. working load (lbs)	100	120	175	220	250

## 2020 order form

Use dimension chart to select appropriate size.

	R310 size 1		R320 size 2		R330 size 3		R340 size 4		R350 size 5	
* <b>Compass chair</b>	R311	\$305 <input type="checkbox"/>	R321	\$330 <input type="checkbox"/>	R331	\$355 <input type="checkbox"/>	R341	\$385 <input type="checkbox"/>	R351	\$410 <input type="checkbox"/>
<b>Seat belt</b>	R312	\$40 <input type="checkbox"/>	R312	\$40 <input type="checkbox"/>	R332	\$40 <input type="checkbox"/>	R342	\$40 <input type="checkbox"/>	R342	\$40 <input type="checkbox"/>
<b>Stability feet</b>	R316	\$60 <input type="checkbox"/>	R316	\$60 <input type="checkbox"/>	R316	\$60 <input type="checkbox"/>	R316	\$60 <input type="checkbox"/>	R316	\$60 <input type="checkbox"/>
<b>Total</b>	<b>R310</b>	\$ _____	<b>R320</b>	\$ _____	<b>R330</b>	\$ _____	<b>R340</b>	\$ _____	<b>R350</b>	\$ _____

\* Required